

KEYPAD INSTRUCTIONS



HOW TO TURN ON YOUR KEYPAD:

- Press the power button on the lower right hand corner of the device.
- You will see numbers and a battery meter on your screen and that is how you'll know your device is on.

Keypad Instructions



HOW TO VERIFY YOUR VOTE:

- If you can't read the serial number on the back of your device, press the button on the lower left hand corner of the device.
- You will see a number appear in the upper left of the display. This number along with the number at the top is what you can use to verify your vote.

Keypad Instructions



HOW TO CAST YOUR VOTE FOR A RESOLUTION:

Press the number that corresponds with your choice.

For example:

Press **1** for Yes

Press **2** for No

HOW TO CHANGE YOUR VOTE:

- Simply enter your new choice.
- The last number you enter will be captured.
- **COUNTED** will appear once your vote has been cast.

Single Selection Voting



HOW TO CAST YOUR VOTE FOR AN ELECTION:

- When verbally prompted and your keypad displays “Vote Now”, enter the number associated with the candidate you wish to choose.
- The number you select will appear in keypad display.
- Use the **DEL** button as backspace if necessary.
- **COUNTED** will appear once your vote has been cast.

Election Voting

